



**WORKZONE**

## Outdoor Socket with Dawn Sensor

User Manual



English.....2

### AFTER SALES SUPPORT



GB

0333 200 5846

IRE

1890 917 060



[accessionx-uk@teknihall.com](mailto:accessionx-uk@teknihall.com)

MODEL: 1472

PRODUCT CODE: 73144

11/2016

Type: Garden/outdoor use



## INTRODUCTION

Outdoor Socket is a dusk to dawn sensor with AC power sockets, built-in 2 PCS 250V/13A UK sockets. At dawn the sockets have no AC voltage while at dusk the AC voltage output will activate.

## FEATURES

- Input Voltage Range: 90-264V
- Working frequency: 47~63HZ
- Ingress Protection level: IP54

## APPLICATION

- Outdoor Fountain
- Outdoor Landscape lamp
- Outdoor Garden light

## DRAWING



## AFTER SALES SUPPORT

GB 0333 200 5846 IRE 1890 917 060

GB Hotline Costs / IRE Hotline Costs

accessionx-uk@teknihall.com

MODEL: 1472 PRODUCT CODE: 73144 11/2016

## PARAMETERS

AC Working voltage range	90V~264V
AC Working frequency	47~63HZ
AC Rated output current	10A (2PCS sockets total 10A)
AC Max output current	13A (2PCS sockets total 13A)
Ingress Protection level	IP54
AC wire diameter	1.5mm <sup>2</sup>
Sockets no-load loss	<2MA
Working temperature	-35°C / +65°C

## INSTALLATION

- Carefully unpack the contents and check to make sure all parts are present, following this insert the plastic stake plug into the bottom hole of the sockets.
- Choose a suitable location for the AC socket giving careful consideration to the nearest suitable outlet, trip hazard etc. Push the socket firmly into the ground and plug in the socket.
- Lastly, insert the appliance into the 2 sockets.
- There are two different power options, with the switch on the backside.
  - On: The power will always be on.
  - Sensor: The power will only be on from dusk till dawn.

## ATTENTION

This product has a waterproof level of IP54, this means it can withstand splashes of water, but not large bodies of water.

This product contains 2 built-in sockets. If you are only using one socket the rated current can reach 10A, with a max. current of 13A, but reaching 13A for extended periods of time can damage the socket and internal components, therefore must be avoided.

If you use 2 sockets at a time the max. current should not exceed 13A.

## DISPOSAL



Electrical and electronic equipment (EEE) contain materials, parts and substances, which can be dangerous to the environment and harmful to human health if waste of electrical and electronic equipment (WEEE) are not disposed of correctly.

Contact your Local Authority Waste Disposal Department, as they will be able to provide details of the recycling options available in your area.

## AFTER SALES SUPPORT

 GB 0333 200 5846 IRE 1890 917 060

GB Hotline Costs / IRE Hotline Costs

 [accessionx-uk@teknihall.com](mailto:accessionx-uk@teknihall.com)

MODEL: 1472 PRODUCT CODE: 73144 11/2016



## WARRANTY CONDITIONS

Dear Customer,

The **Aldi warranty** offers you extensive benefits compared to the statutory obligation arising from a warranty:

**Warranty period:** **3 years** from the date of purchase  
**6 months** for wear parts and consumables under normal and proper conditions of use (e.g. rechargeable batteries).

**Costs:** Free repair/ exchange or refund. No transport costs.

**Hotline:** Calls cost 5p per minute from a landline, calls from mobiles may vary.

**ADVICE:** Please contact our service hotline by phone, email or fax before sending in the device. This allows us to provide support in the event of possible operator errors.

**In order to make a claim under the warranty, please send us:**



- together with the faulty item the original receipt and the warranty card properly completed.
- the faulty product with all components included in the packaging.

**The warranty does not cover damage caused by:**

- Accident or unanticipated events (e.g. lightning, water, fire).
- Improper use or transport.
- Disregard of the safety and maintenance instructions.
- Other improper treatment or modification.

After the expiry of the warranty period, you still have the possibility to have your product repaired at your own expense. If the repair or the estimate of costs is not free of charge you will be informed accordingly in advance.

### AFTER SALES SUPPORT

  0333 200 5846  1890 917 060

GB Hotline Costs / IRE Hotline Costs

 [accessionx-uk@teknihall.com](mailto:accessionx-uk@teknihall.com)

MODEL: 1472 PRODUCT CODE: 73144 11/2016



# WARRANTY CARD



## OUTDOOR SOCKET WITH DAWN SENSOR

Your details:

Name \_\_\_\_\_

Address \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

 \_\_\_\_\_ E-mail \_\_\_\_\_

Date of purchase\* \_\_\_\_\_

\*We recommend you keep the receipt with this warranty card

Location of purchase \_\_\_\_\_

Description of malfunction:



Return your completed  
warranty Card to:

Telemarcom Service Center UK  
1, Langlands Court  
Kelvin South Business Park  
East Kilbride ,  
G75 0YB  
United Kingdom  
E-mail: [accessionx-uk@teknihall.com](mailto:accessionx-uk@teknihall.com)

### AFTER SALES SUPPORT

  **0333 200 5846**  
  **1890 917 060** [accessionx-uk@teknihall.com](mailto:accessionx-uk@teknihall.com)

MODEL: 1472

PRODUCT CODE: 73144

11/2016

Phone lines available  
Monday to Friday, 8am - 6pm.  
Calls cost 5p per minute from  
a landline, calls from mobiles  
may vary.

# 3

YEAR WARRANTY